

Seat upholstery - seat depth - concepts

The image below shows the concepts used with seat depth and how we measure them.

Effective seat depth (A) is measured from the middle of the back upholstery to the front of the seat. It varies depending of how much you slack the back upholstery and the back angle you use. It's the same depth as the cushion.

Seat depth (B) is measured from the backrest frame to the front of the seat upholstery. It's the measure used in brochures and technical data.

Seat upholstery, length (C) is the actual measure of the seat upholstery. It's measured in millimeters.

Seat width (D) is the seat width of the chair.

News!

We have added "**Seat upholstery, length (C)**" in the description of the seat upholstery.

Eg. "**Seat upholstery S2 Short 36 (246mm)**" where "(246mm)" stands for the seat upholstery length.

