

Assembly:

- 1. Take the plastic plate (1) and place it on your curved footrest as shown in figure 1.
- 2. Pull down the straps (2) through the holes in the plate and around the tubing of the footrest.
- 3. Thread the ends through the tops of the straps to fix the plate onto the footrest. Tighten securely and cut off the remaining lengths of the straps.

