



Bromsar på standard modeller

		standard denna konfig	balansläge - bakaxel																																						
			14	16	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46	48	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78	80	82	84	86	88	90
S3	20	std	42												Balansläge																										
	22	std	36												Balansläge																										
	24	std																																							
	25	std																																							
	26	std																																							
S3 kort	20	BF	42												Balansläge																										
	22	BF	36												Balansläge																										
	24	std																			Balansläge																				
	25	std																			Balansläge																				
	26	std																			Balansläge																				
U3	22	std	36												Balansläge																										
	24	std																																							
	25	FF																			Framflyttad																				
	26	FF																			Framflyttad																				
U3 Light	22	std																																							
	24	std																																							
	25	FF																																							
	26	FF																																							
U3 Light L	22	std																																							
	24	std																																							
	25	FF																																							
	26	FF																																							
S3 Swing	20	BF	42												Balansläge																										
	22	BF	36												Balansläge																										
	24	std																			Balansläge																				
	25	std																			Balansläge																				
	26	std																			Balansläge																				
S3 Swing kort	20	BF	42												Balansläge																										
	22	BF	36												Balansläge																										
	24	std																			Balansläge																				
	25	std																			Balansläge																				
	26	std																			Balansläge																				
Large	20	std	42												Balansläge																										
	22	std	36												Balansläge																										
	24	std																																							
	25	std																																							
	26	std																																							
Kort Låg	20	BF	42												Balansläge																										
	22	BF	36												Balansläge																										
	24	std																			Balansläge																				
	25	std																			Balansläge																				
	26	std																			Balansläge																				



Fungerar men låsarm går inte helt tillbaka

Fungerar ej